

**Searcy High School
Stage Specs**

PROSCENIUM AND STAGE DIMENSIONS:

Acting Area: 50' 10" width x 41 ½' depth
Lip of apron to upstage barrier mid-stage
traveller 27'3"

LOADING AREA:

Located	Upstage left
Dock Load doors	12' x 12'
Stage Load doors	12' x 12'
Distance from dock to stage doors-approx.	41'

FOH SOUND SYSTEM:

- Control Board Midas 32
- CD player
- iPod/MP3 Player Dock (auxiliary cord)
- A backstage mic will be available

HOUSE COMMUNICATIONS:

Intercom from stage manager to control booth

STAGE LIGHTING:

Light Board: ETC Nomad with a programming wing

Lights will be set up on faders to control:

- House Lights
- Podium Special
- Full Stage Wash
- Stage Wash Colors (RGB)
- Cyc Wash
- 3 zones across the stage, two zones deep. Up Right, Up Center, Up Left, Down Right, Down Center, Down Left
- 2 Follow Spots will be available for use